Johnson®
OUTBOARDS

Service Manual

40 thru 55

2-CYLINDER

EVINRUDE®
OUTBOARDS

Download this Manual

Outboard Models Covered in This Service Manual

25 Models

E25DRLEO	J25DRLEO
E25DELEO	J25DELEO
E25DTLEO	J25DTLEO
E25DREO	J25DREO
E25DEEO	J25DEEO

40 Models

E40REO	40RSM	J40REO
E40RLEO	40RSLM	J40RLEO
E40BAEO	40RSYM	J40BAEO
E40BALEO	40RWLP	J40BALEO
E40EEO	40RPP	J40EEO
E40ELEO	40RPLP	J40ELEO
E40TEEO	40RPYP	J40TEEO
E40TELEO		J40TELEO
E40TLEO		J40TLEO
E40TTLEO		J40TTLEO

45 Models

45RSP
45RSLP
45RSYP
45RCEO
45RCLEO

48 Models

E48ESLEO	J48ESLEO

50 Models

E50BEEO	J50BEEO
E50BELEO	J50BELEO
E50TELEO	J50TELEO
E50TLEO	J50TLEO
E50JEO	J50JEO

55 Models

55RSG
55RSLG
55RSYG
55WMLG

Download this Manual



33673



22083



36593



31329



15602A



31159



31486



31486

Download this Manual